




SUPAPOLY

Rainwater Tanks

FIT OUT GUIDE

Inlet Positions



Roof of tank
C only position
available


Firstly you need to imagine you are looking down on the top of the tank from an aerial view and that is like a clock face. Imagine that the inlet is in the centre. The inlet is where you will attach the tank to your down pipe or gutter to collect your rainwater.

Your outlet is where you connect your tank to the pump or a tap this is set at 12 o'clock.

You will need to work out where you would like your overflow to be drilled. Your overflow is drilled in the very top of the tank and this is where you will connect the tank to the storm water. The overflow can be drilled at any of the 5 positions indicated on the face. Your tank will come with a short overflow pipe that has a mozzie cover.

Outlet Positions


12



3 Bottom of tank
12 only position
available

Over Flow Positions

5



1 Top of tank
Any of the 5
positions